

DESCRIPTION

KS24 is a three-phase AC output panel mount type SSR (3PST-NO). It offers 4~32VDC input voltage option and two AC output voltage options 380VAC and 480VAC as well as six output current ratings from 10A to 60A for selection. The SSR includes an LED indicator to display working status and provides photoelectric isolation between input and output with dielectric strength 4000V and offers two alternative switching modes: zero-cross turn-on and random turn-on. Besides, the phase absence protection type is equipped with an additional neutral terminal to realize the corresponding function. KS24 can be used in the control of three-phase motors, heaters, etc.

FEATURES

- Photoelectric isolation
- LED status indicator
- Dielectric strength 4000V
- Zero-cross or random turn-on

Removable protective cover

- Built-in RC snubber circuit
- Panel mount

PRECAUTIONS

- 1. The surge current value shown on this datasheet is the nonrepetitive peak value of the surge current of the SSR. Normally 1/2 of the non-repetitive peak value of the surge current is considered as standard value. If the actual surge current flowing through the SSR exceeds the standard value, a semiconductor fuse is required to connect to the output terminal in series in order to prevent any damage caused to the SSR.
- 2. Please ensure that the SSR can withstand the transient voltage in case the output load (e.g. motors) may generate the high shock voltage.
- 3. The transient voltage value shown on this datasheet is the non-repetitive peak value of the transient voltage. If the transient voltage applied to the output terminal of the SSR exceeds the nominal value, a varistor is required to connect to the output terminal in parallel in order to prevent any damage caused to the SSR. And the recommended varistor voltage is 750~1000V.
- 4. When the phase absence or phase failure problem occurs to

the three-phase power supply, the phase absence protection type SSR will rapidly stop all the output and turn off the LED indicator and then run into self-lock mode till the input power supply is cut off and re-electrified. The terminals L1, L2, L3 and N must connect to the three-phase power supply, and the terminals U, V and W must connect to the three-phase load, otherwise the phase absence protection function will not be able to work.


- 5. Please pay special attention to the actual load current and the ambient temperature when doing the type selection. And the SSR requires proper heat sinking for heat dissipation in full load. When the ambient temperature is high, the load current must be derated. Please refer to the curve of Max. Load Current vs. Ambient Temperature for derating.
- 6. Tighten the SSR screw terminals properly. If the screws are loose, the SSR would be damaged by heat generated from connection. Also excessive screw mounting torque may

damage the SSR's internal components. Please refer to the recommended screw mounting torque as follows: the M4 screw mounting torque range is 0.98~1.37N·m, and the M3 screw mounting torque range is 0.58~ 0.98N·m.

- 7. It is recommended to use the matched heatsink made by Keysolu. If the user needs to use the home-made heatsinks, please ensure that the temperature of the SSR base must not exceed 85°C.
- 8. Because all the electronic components inside the SSR have become solid after encapsulation with epoxy resin, the excessive baseplate mounting torque may cause damage to the internal components. Thus the recommended mounting torque is 0.98~1.37N·m.
- 9. Please do not use the SSR exceeding the limitation which is specified on this datasheet.

INSTALLATION

- 1. Please make sure that the heatsink surface is clean and smooth.
- 2. Please coat the SSR metal base with some thermal grease or a thermal pad, and firmly press the SSR against the heatsink to ensure the full adherence, and then screw the SSR to the heatsink.
- 3. Please wire the screw terminals and tighten the screws properly. The recommended screw mounting torque is 0.98~1.73N·m.



SELECTION GUIDE

| KS24 / | D- | 38 | Z | 10 | -Y | L | Р | (XXX) |
|--------|--------------------|--------------------------|-------------------|--------------------|------------------------|---------------|--------------------------|--------------------------|
| Туре | Control voltage | Load voltage | Switching mode | Load current | Overvoltage protection | LED indicator | Phase loss protection | Customer special code |
| | D: 4~32VDC | 38: 380VAC 48: 480VAC | Z: Zero-cross | 10: 10A 15: 15A | Y: Included Nil: | L: Included | P: Included Nil: | |
| | | | P: Random | 25: 25A | Not included | | Not included | |
| | | | | 40: 40A 50: 50A | | | | |
| | | | | 60:60A | | | | |

Note: Available parts are:KS24/D-38=10-=L=, KS24/D-38=15-=L=, KS24/D-38=25-=L=, KS24/D-38=40-=L=, KS24/D-48Z40-=L=, KS24/D-38=40-=L=, KS24 KS24/D-48Z50-DLD, KS24/D-48Z60-DLD.

| INPUT SPECIFICATIONS (Ta = 25°C) | | |
|----------------------------------|-----------|--|
| Control voltage range | 4 ~ 32VDC | |
| Must turn-on voltage | 4VDC | |
| Must turn-off voltage | 1VDC | |
| Max. input current | 35mA | |
| Max. reverse protection voltage | -32VDC | |

| | | D-38: 48 ~ 440VAC |
|---------------------------------------|------------|-------------------------------|
| oad voltage range | | D-48: 48 ~ 530VAC |
| | | D-38Z10:10A |
| | | D-38Z15: 15A |
| lax. load current | 7 | D-38Z25: 25A |
| ax. load current | | D-==Z40: 40A |
| | | D-48Z50: 50A |
| | | D-48Z60: 60A |
| 8 | | D-38: 800Vpk |
| x. transient voltage | | D-48: 1200Vpk |
| quency range | | 47 ~ 63Hz |
| | | D-38Z10: 100Apk |
| | | D-38Z15: 150Apk |
| ıx. surge current (10ms) | | D-38Z25: 250Apk |
| x. sarge current (10113) | | D-□□Z40: 400Apk |
| | | D-48Z50: 500Apk |
| | | D-48Z60: 600Apk |
| | | D-38Z10: 50A ² s |
| | | D-38Z15: 112A ² s |
| x. I ² t for fusing (10ms) | | D-38Z25: 312A ² s |
| ent approximation — Northwest | | D-==Z40: 800A²s |
| | | D-48Z50: 1250A²s |
| | | D-48Z60: 1800A ² s |
| ax. on-state voltage drop | | 1.7Vr.m.s. |
| n. load current | | 100mA |
| x. off-state leakage current | | 10mA |
| n, o ff-state dv/dt | | D-38: 200V/μs |
| i, o ii state uvjut | | D-48: 500V/μs |
| ax. turn-on time | Zero-cross | 1/2 Cycle + 1ms |
| | Random | 1ms |
| ax. turn-off time | | 1/2 Cycle + 1ms |
| in. power factor | | 0.5 |


| GENERAL SPECIFICA | ATIONS (Ta = | 25°C) | | | | | |
|--------------------------------|--------------|-----------------|------------------------|------------|-----|-----|--|
| Dielectric strength (input/out | tput) | i. | 4000VAC, 50~60Hz, 1min | | | | |
| Insulation resistance | | 1000MΩ (500VDC) | | | | | |
| Max. capacitance (input / out | | 10pF | | | | | |
| operating temperature | | -30 ~ 80°C | | | | | |
| Storage temperature | | -30 ~ 100°C | | | | | |
| Ambient humidity | | 45% ~ 85% RH | | | | | |
| Termination | | Screw | | | | | |
| Installation method | | | Panel mount | | | | |
| Unit weight | | Approx.315g | | | | | |
| APPLICATION SPECI | FICATIONS (T | a = 25°C) | | | | | |
| Relay load current | 10A | 15A | 25A | 40A | 50A | 60A | |
| Motor power | 0.75kW | 1.1kW | 1.5kW | 3kW | 4kW | 5kW | |
| Heatsink part number | HF92B-150A | | | HF92B-150C | | | |
| Cooling fan air flow | 115CFM | | | | | | |

OUTLINE DIMENSIONS, WIRING DIAGRAM


Unit: mm


Outline Dimensions


KS24 (without phase absence protection)




KS24 (with phase absence protection)








Wiring Diagram







Notes: F1,F2,F3 should be semiconductor fuses

CHARACTERISTIC CURVES

Max. Load Current vs. Ambient Temperature (10A)




Max. Load Current vs. Ambient Temperature (15A)




CHARACTERISTIC CURVES


Max. Load Current vs. Ambient Temperature (25A)




Max. Load Current vs. Ambient Temperature (40A)




Max. Load Current vs. Ambient Temperature (50A)



Max. Load Current vs. Ambient Temperature (60A)



Max. Permissible Non-repetitive Peak Surge Current vs. Continuance Time



Energizing Continuance Time (ms)